

OPERATIONS

WARNING

Certain compressor oils, chemicals, household cleaners, solvents, paints and fumes will attack plastic bowls and can cause bowl failure. Do not use near these materials. When bowl becomes dirty replace bowl or wipe only with clean, dry cloth. Immediately replace any crazed, cracked, damaged or deterior rated plastic bowl with a new plastic bowl.

SOME OF THE MATERIALS THAT WILL ATTACK POLYCARBONATE PLASTIC BOWLS.

Acetaldehvde Acetic acid (conc.) Acetone Acrylonitrile Ammonia Ammonium flouride Ammonium hydroxide Ammonium sulfide Anaerobic adhesives and sealants Antifreeze Benzene Benzoic acid Benzyl alcohol Brake fluids Bromobenzene Butyric acid Carbolic acid Carbon disulfide Carbon tetrachloride Caustic potash solution Caustic soda solution

Chlorobenzene Chloroform Cresol Cyclohexanol Cyclohexanone Cyclohexene Dimethyl formamide Diozane Ethane tetrachloride Ethyl acetate Ethyl ether Ethylamine Ethylene chlorohydrin Ethylene dichloride Ethylene glycol Formic acid (conc.) Freon (refrig. & propell.) Gasoline (high aromatic) Hydrazine Hydrochloric acid (conc.) Lacquer thinner Methyl alcohol

Methylene chloride Methylene salicylate Milk of lime (CaOH) Nitric acid (conc.) Nitrobenzene Nitrocellulose lacquer Phenol Phosphorous hydroxy chloride Phosphorous trichloride Propionic acid Pyridine Sodium hydroxide Sodium sulfide Styrene Sulfuric acid (conc.) Sulphural chloride Tetrahydronaphthalene Tiophene Toluene Turpentine **Xvlene** Perchlorethylene and others

TRADE NAMES OF SOME COMPRESSOR OILS, RUBBER COMPOUNDS AND OTHER MATERIALS THAT WILL ATTACK POLYCARBONATE PLASTIC BOWLS.

Atlas "Perma-Guard" Buna N Cellulube #150 and #220 Crylex #5 cement *Eastman 910 Garlock #98403 (polyurethane) Haskel #568-023 Hilgard Co.'s hil phene Houghton & Co. oil #1120. #1130 & #1055 Houtosafe 1000 Kano Kroil Keystone penetrating oil #2 *Loctite 271 *Locite 290 *Loctite 601 Loctite Teflon-Sealant Marvel Mystery Oil Minn. Rubber 366Y

"Nylock" VC-3 Parco #1306 Neoprene *Permabond #910 Petron PD287 Prestone Pvdraul AC Sears Regular Motor Oil Sinclair oil "Lily White" Stauffer Chemical FYRQUEL #150 Stillman #SR 269-75 (polyurethane) Stillman #SR 513-70 (neoprene) Tannergas Telar Tenneco anderol #495 & #500 oils Titon *Vibra-tite Zerex

National Compound #N11

*When in raw liquid form.

WE CANNOT POSSIBLY LIST ALL HARMFUL SUBSTANCES, SO CHECK WITH MOBAY CHEMICAL OR THE GENERAL ELECTRIC OFFICE FOR FURTHER INFORMATION ON POLY-CARBONATE PLASTIC.

CAUTION

EXCEPT as otherwise specified by the manufacturer, this product is specifically designed for compressed air service, and use with any other fluid (liquid or gas) is a misapplication. For example, use with or injection of certain hazardous liquids or gases in the system (such as alcohol or liquid petroleum gas) could be harmful to the unit or result in a combustible condition or hazardous external leakage. Manufacturer's warranties are void in the event of misapplication, and manufacturer assumes no responsibility for any resulting loss. Before using with fluids other than air, or for nonindustrial applications, or for life support systems consult manufacturer for written approval.

See reverse side for Installation and Maintenance Instructions.

INSTALLATION AND MAINTENANCE SHEET

Filter Model F00 With Variations and Accessories



INSTALLATION

1.Refer to the warning.

- 2. Install as close as possible to point where air is being used.
- 3.Install the unit with the air flowing through the body in the direction indicated by arrow.
- 4.Install the same pipe-size unit as the pipeline in use. Avoid using fittings, couplings, etc., that restrict air flow.
- 5.Do not install this unit on any application where the pressure drop will exceed 20 psi. Downstream from a quick-opening valve, for example, could cause a momentary drop in excess of 20 psi (1,4 bar).
- 6.Maximum inlet pressure and operating temperature ratings are: transparent plastic bowls, 150 psig (10 bar) and 125°F (52°C); metal bowls, 250 psig (17 bar) and 175°F (79°C).

MAINTENANCE

1. EACH TIME THE BOWL IS CLEANED OR THE FILTER ELEMENT REPLACED

A. Depressurize unit.

- B. Inspect and replace crazed, cracked, damaged or deteriorated seals and bowls with original manufacturer's approved seals only.
- C. Inspect bowl and replace crazed, damaged or deteriorated bowl with a new bowl.
- Remove element and clean periodically by tapping on a hard surface, and blowing off with a blow gun.
- 3. IF UNIT IS EQUIPPED WITH A MANUAL DRAIN, drain sump whenever water can be seen in bowl by pushing up on the valve stem.
- Before placing the unit in service, make sure that the bowl and bowl guard are securely locked in place.

REPAIR KITS AND REPLACEMENT PARTS

O-Ring Kit	GRP-95-264
Filter Element Kit	FRP-95-235
Baffle Kit	FRP-95-069
Automatic Piston Drain	GRP-95-584
Plastic Bowl with check valve	GRP-96-310
Plastic Bowl	GRP-95-856
Metal Bowl with check valve	GRP-96-506
Check Valve (for units w/o automatic	
piston drain)	GRP-96-102
Metal Bowl Guard	GRP-96-309

ACCESSORIES

Wall Mounting Bracket	GRP-95-754
Pipe Mounting Bracket	GRP-95-734